

822 1<sup>st</sup> Ave North  
 Escanaba, MI 49829  
 906-786-4603

# PERKS

## CABINETS

W1860 US 41 South  
 Marinette, WI 54143  
 715-735-9721

### How to Measure My Kitchen

No two rooms are the same. Our Kitchen & Bath designers are experts in design and need exact dimensions to customize a new space for you. On a separate piece of paper, create a rough drawing of your room following these measuring guidelines.

**Step 1:** Measure the overall sink window wall. Start in the left corner or end and measure (in inches) to the outside edge of the window trim, if any. Move to the other side of the window and measure from the outside-of-trim to the other corner.

**Step 2:** Measure the window. Mark the width from outside-of-trim to outside-of-trim. Mark the locations of appliances, outlets, and light switches.

**Step 3:** Working clockwise, repeat Step 1 and 2, using the same method of outside-of-trim to outside-of-trim for any other window or door openings. Mark which way the door swings.

**Step 4:** Measure from the center of your sink plumbing to the nearest corner or fixed point.

**Step 5:** Measure your appliances for width (side to side), height (how tall), and depth (front to back), in that order, or provide Part or Model #s

Refrigerator: \_\_\_\_\_ W x \_\_\_\_\_ H x \_\_\_\_\_ D  
 Stove/Cooktop: \_\_\_\_\_ W x \_\_\_\_\_ H x \_\_\_\_\_ D  
 Dishwasher: \_\_\_\_\_ W x \_\_\_\_\_ H x \_\_\_\_\_ D  
 Wall Oven: \_\_\_\_\_ W x \_\_\_\_\_ H x \_\_\_\_\_ D

**Step 6:** Measure the ceiling height in a few different locations. Ceiling heights can vary. Mark this on your plan and label it. If you have soffits (a bulkhead between the ceiling and the top of the cabinets), measure the distance from the floor to the soffit and mark on the plan the width and depth of the soffit.

**Step 7:** Measure the heights of any windows or wall openings from the top outside-of-trim to the ceiling and bottom outside-of-trim to the floor.

